



INSTALLATION PROCEDURE

REPLACEABLE (WET-SET) COMPOSITE TACTILE

Inline Dome Pattern

View additional photos, drawings and specifications on our website: www.adatale.com.
Call (800) 372-0519 with any questions.

◆ **Be sure to read & understand all of these instructions before you begin.**

- A. The physical characteristics of the concrete shall be as specified in the contract documents while maintaining a slump range of 4-7 inches to permit the solid placement of the Paver Tile in the wet cement.
- B. The concrete shall be poured, finished level, true and smooth to the required dimensions prior to the placement of the tile.
- C. Place the tile 6 – 8 inches from the curb line. Working in a grid pattern, tamp the tile into the wet concrete using a rubber mallet and a scrap piece of wood. Continue this process until the tile surface is flush with the surrounding area.
IMPORTANT: Avoid striking the surface of the tile directly.
- D. Following the placement, the tile elevation should be checked to the adjacent surface with a straight edge. The tile elevation should be consistent with the contract drawings and specifications. Any required adjustments must be made prior to the time when the concrete begins to set.
- E. Protect the area from pedestrian traffic for 24 to 48 hours.
- F. Upon curing, remove protective plastic covering.
- G. **To replace the ADA Replaceable unit:**
 - 1. Remove the fastener cap
 - 2. Back-out stainless steel anchor
 - 3. Using a rubber mallet, tamp around the outer edge to release the concrete bond
 - 4. Use a pry bar to remove the ADA Replaceable unit
 - 5. Place a new ADA Replaceable unit in the desired location
 - 6. Re-install stainless steel fastener in existing concrete insert
 - 7. Replace fastener cap

PRODUCT SIZES: 24"x36", 24"x48", 24"x60"
APPLICATION: Fresh Pour Concrete Ramps or Platforms



POUR



PLACE



TAMP



DONE!

ADA SOLUTIONS, INC.

P.O. Box 3, North Billerica MA 01862 Tel: 800.372.0519 Fax: 978.262.9125
www.adatale.com