

1. Read installation instructions thoroughly before you begin. Federal compliance documents can be found on our web site [www.tuftile.com](http://www.tuftile.com)
2. Surface must be clean and free of debris before beginning. A wire brush or cup grinder may be needed to address any imperfections.
3. Place tile on surface where it is to be installed and mark the corners. **(Fig. 1)**
4. Remove and apply sealant to the back side of the tile as required **(Fig. 2)**  
**Note: Use sealant according to manufacturers recommendation.**
5. Place tile in marked location. Using a 1/4" masonry bit, drill 2" minimum deep holes (Fig. 3) and insert 2 drive pin fasteners. (Fig. 4)  
**Note: Do not drive pins in yet as they are to keep tile in place while drilling remaining holes.**
6. Continue drilling holes in the anchor locations going across the tile. **For polymer tiles use center most holes**  
Once all holes are drilled, clean the tile with a broom or blower before inserting the remaining drive pins.
7. Insert drive pins and hammer them in moving across the tile in one direction. (Fig.6)  
**Note: Only drive the pin so that it is even with the head of the anchor**  
**IMPORTANT: WHEN INSTALLING MULTIPLE LINEAR TILES A 1/8" SPACE IS REQUIRED TO ALLOW FOR EXPANSION**


**Note: If a tile is cut, new holes need to be drilled and anchors inserted along the edge**

Installation is now complete


### Radius steps

Place tiles and radius wedge pieces on the surface. Once you're satisfied with the layout, continue with steps 3 - 7 above


**Note: Any adjustments needed should be done before fastening the tiles.**




**Fig. 1**




**Fig. 2**




**Fig. 3**



**Fig. 4**



**Fig. 5**



**Fig. 6**

Additional installation information is available at

[www.tuftile.com](http://www.tuftile.com)

888-960-8897